



Hybrid Inverter

SUN-14K-SG05LP3-EU-SM2

SUN-15K-SG05LP3-EU-SM2

SUN-16K-SG05LP3-EU-SM2

SUN-18K-SG05LP3-EU-SM2

SUN-20K-SG05LP3-EU-SM2

User Manual



Contents

1. Safety Introductions	01-02
2. Product Instructions	02-05
3. Installation	06-27
4. OPERATION	28
5. LCD Display Icons	29-41
6. Mode	42-43
7. Limitation of Liability	43-46
8. Datasheet	47-48
9. Appendix I	49-51
10. Appendix II	52
11. EU Declaration of Conformity	52-53

About This Manual

The manual mainly describes the product information, guidelines for installation, operation and maintenance. The manual cannot include complete information about the photovoltaic (PV) system.








How to Use This Manual

Read the manual and other related documents before performing any operation on the inverter. Documents must be stored carefully and be available at all times.

Contents may be periodically updated or revised due to product development. The information in this manual is subject to change without notice. The latest manual can be acquired via service@deye.com.cn

1. Safety Introductions

Labels description


Label	Description
	Caution, risk of electric shock symbol indicates important safety instructions, which if not correctly followed, could result in electric shock.
	The DC input terminals of the inverter must not be grounded.
	Surface high temperature, Please do not touch the inverter case.
	The AC and DC circuits must be disconnected separately, and the maintenance personnel must wait for 5 minutes before they are completely powered off before they can start working.
	CE mark of conformity
	Please read the instructions carefully before use.
	Symbol for the marking of electrical and electronics devices according to Directive 2002/96/EC. Indicates that the device, accessories and the packaging must not be disposed as unsorted municipal waste and must be collected separately at the end of the usage. Please follow Local Ordinances or Regulations for disposal or contact an authorized representative of the manufacturer for information concerning the decommissioning of equipment.

-
- This chapter contains important safety and operating instructions. Read and keep this manual for future reference.
 - Before using the inverter, please read the instructions and warning signs of the battery and corresponding sections in the instruction manual.
 - Do not disassemble the inverter. If you need maintenance or repair, take it to a professional service center.
 - Improper reassembly may result in electric shock or fire.
 - To reduce risk of electric shock, disconnect all wires before attempting any maintenance or cleaning. Turning off the unit will not reduce this risk.
 - Caution: Only qualified personnel can install this device with battery.
 - Never charge a frozen battery.
 - For optimum operation of this inverter, please follow required specification to select appropriate cable size. It is very important to correctly operate this inverter.
 - Be very cautious when working with metal tools on or around batteries. Dropping a tool may cause a spark or short circuit in batteries or other electrical parts, even cause an explosion.
 - Please strictly follow installation procedure when you want to disconnect AC or DC terminals. Please refer to "Installation" section of this manual for the details.
 - Grounding instructions - this inverter should be connected to a permanent grounded wiring system. Be sure to comply with local requirements and regulation to install this inverter.
 - Never cause AC output and DC input short circuited. Do not connect to the mains when DC input short circuits.

2. Product Introductions

This is a multifunctional inverter, combining functions of inverter, solar charger and battery charger to offer uninterruptible power support with portable size. Its comprehensive LCD display offers user configurable and easy accessible button operation such as battery charging, AC/solar charging, and acceptable input voltage based on different applications.

2.1 Product Overview





- 1: LCD display
- 2: Function buttons
- 3: Battery input connectors
- 4: Function port
- 5: Meter-485 port



- 6: ParallelModbus port
- 7: Modbus port
- 8: BMS port
- 9: Generator input
- 10: Load

- 11: Grid
- 12: DRM port
- 13: Power on/off button
- 14: DC switch
- 15: WiFi Interface
- 16: PV input

2.2 Product Size



Inverter Size



2.3 Product Features

- 230V/400V Three phase Pure sine wave inverter.
- Self-consumption and feed-in to the grid.
- Auto restart while AC is recovering.
- Programmable supply priority for battery or grid.
- Programmable multiple operation modes: On grid, off grid and UPS.
- Configurable battery charging current/voltage based on applications by LCD setting.
- Configurable AC/Solar/Generator Charger priority by LCD setting.
- Compatible with mains voltage or generator power.
- Overload/over temperature/short circuit protection.
- Smart battery charger design for optimized battery performance
- With limit function, prevent excess power overflow to the grid.
- Supporting WIFI monitoring and build-in 2 strings of MPPT trackers.
- Smart settable three stages MPPT charging for optimized battery performance.
- Time of use function.
- Smart Load Function.


2.4 Basic System Architecture

The following illustration shows basic application of this inverter. It also includes following devices to have a Complete running system.

- Generator or Utility
- PV modules

Consult with your system integrator for other possible system architectures depending on your requirements.

This inverter can power all kinds of appliances in home or office environment, including motor type appliances such as refrigerator and air conditioner.




3. Installation

3.1 Parts List

Check the equipment before installation. Please make sure nothing is damaged in the package. You should have received the items in the following package:



Hybrid inverter
x1



Wall mounting bracket x1



Stainless steel anti-collision
bolt M8x80
x4




Parallel communication
cable x1




Sensor Clamp
x3



Battery temperature
sensor x1



User manual x1



Meter(optional)
x1



Datalogger (optional) x1



Magnetic ring for battery
x1



Magnetic ring for BMS
communication cable x1




DC+/DC- Plug connectors
including metal terminal
xN



Solar Photovoltaic
Connector Special
Spanner x1

3.2 Product handling requirements

Lift the inverter out of the packing box and transport it to designated installation location.



CAUTION:

Improper handling may cause personal injury!

- Arrange an appropriate number of personnel to carry the inverter according to its weight, and installation personnel should wear protective equipment such as anti-impact shoes and gloves.
- Placing the inverter directly on a hard ground may cause damage to its metal enclosure. Protective materials such as sponge pad or foam cushion should be placed underneath the inverter.
- Move the inverter by one or two people or by using a proper transport tool.
- Move the inverter by holding the handles on it. Do not move the inverter by holding the terminals.


3.3 Mounting instructions

Installation Precaution

This Hybrid inverter is designed for outdoor use(IP65), Please make sure the installation site meets below conditions:

- Not in direct sunlight
- Not in areas where highly flammable materials are stored.
- Not in potential explosive areas.
- Not in the cool air directly.
- Not near the television Antenna or antenna cable.
- Not higher than altitude of about 3000 meters above sea level.
- Not in environment of precipitation or humidity(>95%)

Please AVOID direct sunlight, rain exposure, snow laying up during installation and operation. Before connecting all wires, please take off the metal cover by removing screws as shown below:




Installations Tools

Installation tools can refer to the following recommended ones. Also, use other auxiliary tools on site.

Protective goggles	Earplugs	Anti-dust mask	Work gloves	Work shoes	Utility knife	Slotted screwdriver
Cross screwdriver	Percussion drill	Pliers	Marker	Level	Rubber hammer	socket wrenches set
Anti-static wrist strap	Wire cutter	Wire stripper	Hydraulic pliers	Heat gun	Crimping tool 4-6mm ²	Solar connector wrench
Multimeter ≥ 1100 Vdc	RJ45 crimping plier	Cleaner				

Considering the following points before selecting where to install:

- Please select a vertical wall with load-bearing capacity for installation, suitable for installation on concrete or other non-flammable surfaces, installation is shown below.
- Install this inverter at eye level in order to allow the LCD display to be read at all times.
- The ambient temperature is recommended to be between -40°C ~ 60°C to ensure optimal operation.
- Be sure to keep other objects and surfaces as shown in the diagram to guarantee sufficient heat dissipation and have enough space for removing wires.




For proper air circulation to dissipate heat, allow a clearance of approx. 50cm to the side and approx. 50cm above and below the unit. And 100cm to the front.


Mounting the inverter

Remember that this inverter is heavy! Please be careful when lifting out from the package. Choose the recommend drill head(as shown in below pic) to drill 4 holes on the wall, 82-90mm deep.

1. Use a proper hammer to fit the expansion bolt into the holes.
2. Carry the inverter and holding it, make sure the hanger aim at the expansion bolt, fix the inverter on the wall.
3. Fasten the screw head of the expansion bolt to finish the mounting.



Inverter hanging plate installation



3.4 Battery connection

For safe operation and compliance, a separate DC over-current protector or disconnect device is required between the battery and the inverter. In some applications, switching devices may not be required but over-current protectors are still required. Refer to the typical amperage in the table below for the required fuse or circuit breaker size:

<i>Model</i>	<i>Wire Size</i>	<i>Cable(mm²)</i>	<i>Torque value(max)</i>
14/15/16kW	0AWG	50	24.5Nm
18/20kW	3/0AWG	70	24.5Nm

Chart 3-2 Cable size




All wiring must be performed by a professional person.





Connecting the battery with a suitable cable is important for safe and efficient operation of the system. To reduce the risk of injury, refer to Chart 3-2 for recommended cables.

Please follow below steps to implement battery connection:

1. Please choose a suitable battery cable with correct connector which can well fit into the battery terminals.
2. Use a suitable screwdriver to unscrew the bolts and fit the battery connectors in, then fasten the bolt by the screwdriver, make sure the bolts are tightened with torque of 24,5 N.M in clockwise direction.
3. Make sure polarity at both the battery and inverter is correctly connected.



For 14/15/16/18/20kW model, battery connector screw size: M8



4. In case of children touch or insects go into the inverter, Please make sure the inverter connector is fasten to waterproof position by twist it clockwise.






Installation must be performed with care.



Before making the final DC connection or closing DC breaker/disconnect, be sure positive(+) must be connect to positive(+) and negative(-) must be connected to negative(-). Reverse polarity connection on battery will damage the inverter.

3.3.2 Function port definition



CN1:

TEMP (1,2): battery temperature sensor for lead acid battery.

CT-L1 (3,4): current transformer (CT1) for "zero export to CT" mode clamps on L1 when in three phase system.

CT-L2 (5,6): current transformer (CT2) for "zero export to CT" mode clamps on L2 when in three phase system.

CT-L3 (7,8): current transformer (CT3) for "zero export to CT" mode clamps on L3 when in three phase system.

CN2:

G-start (1,2): dry contact signal for startup the diesel generator.

When the "GEN signal" is active, the open contact (GS) will switch on (no voltage output).

G-valve (3,4): Dry contact output. When the inverter is in off-grid mode and the "signal island mode" is checked, the dry contact will switch on.

Grid_Ry (5,6): reserved.

RSD (7,8): When battery is connected and the inverter is in "ON" status, it will provide 12Vdc.

RSD_input (9,10,+,-): when the terminal "B" & "B" is short-circuited with additional wire connection, or there's 12Vdc input at the terminal "+" & "-", then the 12Vdc of RSD+ & RSD- will disappear immediately, and the inverter will shutdown immediately.



Parallel A: Parallel communication port 1 (CAN interface).


Parallel B: Parallel communication port 2 (CAN interface).

Meter_485: for energy meter communication.


Modbus: Reserved.

BMS: BMS port for battery communication (CAN/RS485).

DRM: It is used to accept the external input signal (Digital input). More details please refer to the P50.



3.4.3 Temperature sensor connection for lead-acid battery



3.5 Grid connection and backup load connection

- Before connecting to the grid, a separate AC breaker must be installed between the inverter and the grid, and also between the backup load and the inverter. This will ensure the inverter can be securely disconnected during maintenance and fully protected from over current. The recommended of AC breaker for the load port is 100A for 14/15/16/18/20kW
The recommended of AC breaker for the grid port is 100A for 14/15/16/18/20kW.
- There are three terminal blocks with "Grid" "Load" and "GEN" markings. Please do not misconnect input and output connectors.



Note:

In final installation, breaker certified according to IEC 60947-1 and IEC 60947-2 shall be installed with the equipment.

All wiring must be performed by a qualified personnel. It is very important for system safety and efficient operation to use appropriate cable for AC input connection. To reduce risk of injury, please use the proper recommended cable as below.

Grid connection and backup load connection (Copper wires)

Model	Wire Size	Cable(mm ²)	Torque value(max)
14/15/16kW	12AWG	2.5	1.2Nm
18/20kW	10AWG	4	1.2Nm


Grid connection and backup load connection (Copper wires) (bypass)

Model	Wire Size	Cable(mm ²)	Torque value(max)
14/15/16/18/20kW	4AWG	16	1.2Nm


Chart 3-3 Recommended Size for AC wires

Please follow below steps to implement Grid, load and Gen port connection:

- Before making Grid, load and Gen port connection, be sure to turn off AC breaker or disconnecter first.
- Remove insulation sleeve 10mm length, unscrew the bolts. For GRID port, just insert the wires into the terminals according to polarities indicated on the terminal block. For GEN and Load ports, thread the wires through the magnetic ring firstly, then insert these wires into the terminals according to polarities indicated on the terminal block. Tighten the terminal screws and make sure the wires are completely and safely connected.



GRID LOAD GEN





Be sure that AC power source is disconnected before attempting to wire it to the unit.

3. Then, insert AC output wires according to polarities indicated on the terminal block and tighten terminal. Be sure to connect corresponding N wires and PE wires to related terminals as well.
4. Make sure the wires are securely connected.
5. Appliances such as air conditioner are required at least 2-3 minutes to restart because it is required to have enough time to balance refrigerant gas inside of circuit. If a power shortage occurs and recovers in short time, it will cause damage to your connected appliances. To prevent this kind of damage, please check manufacturer of air conditioner if it is equipped with time-delay function before installation. Otherwise, this inverter will trigger overload fault and cut off output to protect your appliance but sometimes it still causes internal damage to the air conditioner

3.6 PV Connection

Before connecting to PV modules, please install a separately DC circuit breaker between inverter and PV modules. It is very important for system safety and efficient operation to use appropriate cable for PV module connection. To reduce risk of injury, please use the proper recommended cable size as below.

<i>Model</i>	<i>Wire Size</i>	<i>Cable(mm²)</i>
14/15/16/18/20kW	12AWG	2.5

Chart 3-4 Cable size



To avoid any malfunction, do not connect any PV modules with possible current leakage to the inverter. For example, grounded PV modules will cause current leakage to the inverter. When using PV modules, please ensure the PV+ & PV- of solar panel is not connected to the system ground bar.



It is requested to use PV junction box with surge protection. Otherwise, it will cause damage on inverter when lightning occurs on PV modules.

3.6.1 PV Module Selection:

When selecting proper PV modules, please be sure to consider below parameters:

- 1) Open circuit Voltage (Voc) of PV modules not exceeds max. PV array open circuit voltage of inverter.
- 2) Open circuit Voltage (Voc) of PV modules should be higher than min. start voltage.
- 3) The PV modules used to connected to this inverter shall be Class A rating certified according to IEC 61730.

<i>Inverter Model</i>	<i>14kW</i>	<i>15kW</i>	<i>16kW</i>	<i>18kW</i>	<i>20kW</i>
PV Input Voltage	550V (160V-800V)				
PV Array MPPT Voltage Range	160V-650V				
No. of MPP Trackers	2				
No. of Strings per MPP Tracker	2+1				

Chart 3-5

3.6.2 PV Module Wire Connection:

1. Switch the Grid Supply Main Switch(AC)OFF.
2. Switch the DC Isolator OFF.
3. Assemble PV input connector to the inverter.



Safety Hint:

When using PV modules, please ensure the PV+ & PV- of solar panel is not connected to the system ground bar.



Safety Hint:

Before connection, please make sure the polarity of the output voltage of PV array matches the "DC+" and "DC-" symbols.



Safety Hint:

Before connecting inverter, please make sure the PV array open circuit voltage is within the 800V of the inverter.



Pic 3.1 DC+ male connector



Pic 3.2 DC- female connector




Safety Hint:

Please use approved DC cable for PV system.


The steps to assemble the DC connectors are listed as follows:

a) Strip off the DC wire about 7mm, disassemble the connector cap nut (see picture 3.3).



Pic 3.3 Disassemble the connector cap nut

b) Crimping metal terminals with crimping pliers as shown in picture 3.4.




Pic 3.4 Crimp the contact pin to the wire

- c) Insert the contact pin to the top part of the connector and screw up the cap nut to the top part of the connector. (as shown in picture 3.5).



Pic 3.5 connector with cap nut screwed on

- d) Finally insert the DC connector into the positive and negative input of the inverter, shown as picture 3.6.



Pic 3.6 DC input connection



Warning:


Sunlight shines on the panel will generate voltage, high voltage in series may cause danger to life. Therefore, before connecting the DC input line, the solar panel needs to be blocked by the opaque material and the DC switch should be 'OFF', otherwise, the high voltage of the inverter may lead to life-threatening conditions.



Warning:



Please use its own DC power connector from the inverter accessories. Do not interconnect the connectors of different manufacturers. Max. DC input current should be 20A. if exceeds, it may damage the inverter and it is not covered by Deye warranty.

3.7 CT Connection



*Notewhen the reading of the load power on the LCD is not correct, please reverse the CT arrow.

3.7.1 Meter Connection




**Note:**

When the inverter is in the off-grid state, the N line needs to be connected to the earth.

3.8 Earth Connection(mandatory)

Ground cable shall be connected to ground plate on grid side, this prevents electric shock if the original protective conductor fails.



Earth connection (Copper wires)

Model	Wire Size	Cable(mm ²)	Torque value(max)
14/15/16kW	12AWG	2.5	1.2Nm
18/20kW	10AWG	4	1.2Nm

Earth connection (Copper wires) (bypass)

Model	Wire Size	Cable(mm ²)	Torque value(max)
14/15/16/18/20kW	4AWG	16	1.2Nm

**Warning:**

Inverter has built-in leakage current detection circuit, The type A RCD can be connected to the inverter for protection according to the local laws and regulations. If an external leakage current protection device is connected, its operating current must be equal to 300 mA or higher, otherwise inverter may not work properly.


3.9 WIFI Connection

For the configuration of Wi-Fi Plug, please refer to illustrations of the Wi-Fi Plug. The Wi-Fi Plug is not a standard configuration, it's optional.

3.10 Wiring System for Inverter

This diagram is an example for an application that neutral connects with the PE in a distribution box.


For countries such as Australia, New Zealand, etc., please follow local wiring regulations!




3.11 Wiring diagram


This diagram is a nexample for a napplication in which neutral | is separated from the PE in the distribution box. For countries such as China, Germany, the Czech Republic, Italy, etc., please follow local wiring regulations!

Note: Backup function is optional in German market, please leave backup side empty if backup function is not available in the inverter.






3.12 Typical application diagram of diesel generator



3.13 Three phase parallel connection diagram



4. OPERATION

4.1 Power ON/OFF

Once the unit has been properly installed and the batteries are connected well, simply press On/Off button(located on the left side of the case) to turn on the unit. When system without battery connected, but connect with either PV or grid, and ON/OFF button is switched off, LCD will still light up(Display will show OFF). In this condition, when switch on ON/OFF button and select NO battery,system can still working.

4.2 Operation and Display Panel

The operation and display panel, shown in below chart, is on the front panel of the inverter. It includes four function keys and a LCD display, indicating the operating status and input/output power information.

<i>Function Key</i>	<i>Description</i>
Esc	To exit setting mode
Up	To go to previous selection
Down	To go to next selection
Enter	To confirm the selection

Chart 4-1 Function Buttons

5. LCD Display Icons

5.1 Main Screen

The LCD is touchscreen, below screen shows the overall information of the inverter.



1.The icon in the center of the home screen indicates that the system is Normal operation. If it turns into "comm./F01~F64", it means the inverter has communication errors or other errors, the error message will display under this icon(F01-F64 errors, detail error info can be viewed in the System Alarms menu).


2.At the top of the screen is the time.

3.System Setup Icon, Press this set button,you can enter into the system setup screen which including Basic Setup, Battery Setup, Grid Setup, System Work Mode, Generator port use, Advanced function and Li-Batt info.


4.The main screen showing the info including Solar, Grid, Load and Battery. Its also displaying the energy flow direction by arrow. When the power is approximate to high level, the color on the panels will changing from green to red so system info showing vividly on the main screen.

- PV power and Load power always keep positive.
- Grid power negative means sell to grid, positive means get from grid.
- Battery power negative means charge, positive means discharge.

5.1.1 LCD operation flow chart




5.2 Solar Power Curve



This is Solar Panel detail page.


- ① Solar Panel Generation.
- ② Voltage, Current, Power for each MPPT.
- ③ Solar Panel energy for Day and Total.

Press the "Energy" button will enter into the power curve page.



This is Inverter detail page.

- ① Inverter Generation.
- Voltage, Current, Power for each Phase.
- AC-T: mean Heat-sink temperature.



This is Load detail page.

- ① Load Power.
- ② Voltage, Power for each Phase.
- ③ Daily and total Load consumption.

When you check "Selling First" or "Zero export to Load" on system work mode page, the information on this page is about backup load which connect on Load port of hybrid inverter.

When you check "Zero export to CT" on system work mode page, the information on this page is including backup load and home load.

Press the "Energy" button will enter into the power curve page.



This is Grid detail page.

- ① Status, Power, Frequency.
- ② L: Voltage for each Phase
CT: Power detected by the external current sensors
LD: Power detected using internal sensors on AC grid in/out breaker
- ③ BUY: Energy from Grid to Inverter,
SELL: Energy from Inverter to grid.

Press the "Energy" button will enter into the power curve page.

Batt

Discharge

U: 49.58V

I: 2.04A

Power: 101W

Temp: 25.0C

Energy


if you use Lithium Battery, you can enter BMS page

Li-BMS		
Mean Voltage: 50.24V	Charging Voltage: 58.2V	<div>Sum Data</div> <div>Delete Data</div>
Total Current: 35.05A	Discharging Voltage: 47.2V	
Mean Temp: -23.5C	Charging current: 50A	
Total SOC: 38%	Discharging current: 25A	
Dump Energy: 5146		
Request Force Charge		

LI-BMS									
	Volt	Cur	Temp	SOC	Energy	Charge	Fast		
1	3.850V	10.70A	35.02C	80.0%	36.86Wh	0.57	0.65	open	Sum Data
2	3.850V	10.70A	35.02C	80.0%	36.86Wh	0.57	0.65	open	
3	3.850V	10.70A	35.02C	80.0%	36.86Wh	0.57	0.65	open	
4	3.850V	10.70A	35.02C	80.0%	36.86Wh	0.57	0.65	open	
5	3.850V	10.70A	35.02C	80.0%	36.86Wh	0.57	0.65	open	Delete Data
6	3.850V	10.70A	35.02C	80.0%	36.86Wh	0.57	0.65	open	
7	3.850V	10.70A	35.02C	80.0%	36.86Wh	0.57	0.65	open	
8	3.850V	10.70A	35.02C	80.0%	36.86Wh	0.57	0.65	open	
9	3.850V	10.70A	35.02C	80.0%	36.86Wh	0.57	0.65	open	
10	3.850V	10.70A	35.02C	80.0%	36.86Wh	0.57	0.65	open	
11	3.850V	10.70A	35.02C	80.0%	36.86Wh	0.57	0.65	open	
12	3.850V	10.70A	35.02C	80.0%	36.86Wh	0.57	0.65	open	

Solar power curve for daily, monthly, yearly and total can be roughly checked on the LCD, for more accuracy power generation, pls check on the monitoring system. Click the up and down arrow to check power curve of different period.

5.4 System Setup Menu



This is System Setup page.

5.5 Basic Setup Menu



Factory Reset: Reset all parameters of the inverter.
Lock out all changes: Enable this menu for setting parameters that require locking and cannot be set up. Before performing a successful factory reset and locking the systems, to keep all changes you need to type in a password to enable the setting.
The password for factory settings is 9999 and for lock out is 7777.



Factory Reset Password: 9999

Lock out all changes Password: 7777

5.6 Battery Setup Menu

Battery Setting

Batt Mode

☐ Lithium **Batt Capacity** 400Ah
☐ Use Batt V **Max A Charge** 40A
☐ Use Batt % **Max A Discharge** 40A
☐ No Batt ☐ **Activate Battery**

Batt Mode

Battery capacity: it tells hybrid inverter to know your battery bank size.

Use Batt V: Use Battery Voltage for all the settings (V).

Use Batt %: Use Battery SOC for all the settings (%).

Max. A charge/discharge: Max battery charge/discharge current (0-260A for 14kW model, 0-280A for 15kW model, 0-300A for 16kW model, 0-330A for 18kW model, 0-350A for 20kW model).

For AGM and Flooded, we recommend Ah battery size x 20% = Charge/Discharge amps.

For Lithium, we recommend Ah battery size x 50% = Charge/Discharge amps.

For Gel, follow manufacturer's instructions.

No Batt: tick this item if no battery is connected to the system.

Active battery: This feature will help recover a battery that is over discharged by slowly charging from the solar array or grid.

Battery Setting

Start 30% **30%** ②
A ① 40A **40A**
☐ Gen Charge ☐ Grid Charge
☐ Gen Signal ☐ Grid Signal
Gen Max Run Time 24.0 hours ③
Gen Down Time 0.0 hours

Batt Set2

This is Grid Charge, you need select. ②

Start =30%: No use. Just for customization.

A = 40A: It indicates the Current that the Grid charges the Battery.

Grid Charge: It indicates that the grid charges the battery.

Grid Signal: Disable.

This is Battery Setup page. ①③

Start =30%: Percent S.O.C at 30% system will AutoStart a connected generator to charge the battery bank.


A = 40A: Charge rate of 40A from the attached generator in Amps.

Gen Charge: uses the gen input of the system to charge battery bank from an attached generator.

Gen Signal: Normally open relay that closes when the Gen Start signal state is active.

Gen Max Run Time: It indicates the longest time Generator can run in one day, when time is up, the Generator will be turned off. 24H means that it does not shut down all the time.

Gen Down Time: It indicates the delay time of the Generator to shut down after it has reached the running time.



This page tells the PV and diesel generator power, the load and battery.

Generator

Power: 6000W Today=10 KWH
Total =10 KWH

V_L1: 230V P_L1: 2KW
V_L2: 230V P_L2: 2KW
V_L3: 230V P_L3: 2KW

This page tells generator output voltage, frequency, power. And, how much energy is used from generator.

Battery Setting

Lithium Mode: 00

Shutdown: 10%

Low Batt: 20%

Restart: 40%

↑ Batt Bt3
↓
✕
✓

Lithium Mode: This is BMS protocol. Please reference the document (Approved Battery).

Shutdown 10%: It indicates the inverter will shutdown if the SOC below this value.

Low Batt 20%: It indicates the inverter will alarm if the SOC below this value.

Restart 40%: Battery voltage at 40% AC output will resume.

Battery Setting

Float V ① 53.6V

Absorption V 57.6V

Equalization V 57.6V

Equalization Days 20 days

Equalization Hours 3.0

Shutdown ③ 20%

Low Batt 35%

Restart 50%

TEMPCO (mV/C/Cell)

② -5

Batt Resistance 25mOhms

↑ Batt Bt3
↓
✕
✓

There are 3 stages of charging the Battery . ①

This is for professional installers, you can keep it if you do not know. ②

Shutdown 20%: The inverter will shutdown if the SOC below this value.

Low Batt 35%: The inverter will alarm if the SOC below this value. ③

Restart 50%: Battery SOC at 50% AC output will resume.

Recommended battery settings

Battery Type	Absorption Stage	Float Stage	Equalization Voltage (every 30 days 3hr)
AGM (or PCC)	14.2V (57.6V)	13.4V (53.6V)	14.2V (57.6V)
Gel	14.1V (56.4V)	13.5V (54.0V)	
Wet	14.7V (59.0V)	13.7V (55.0V)	14.7V (59.0V)
Lithium	Follow its BMS voltage parameters		

5.7 System Work Mode Setup Menu

System Work Mode

☐ Selling First 12000 Max Solar Power ↑
Work Mode
↓
☐ Zero Export To Load ☒ Solar Sell
☐ Zero Export To CT ☒ Solar Sell
Max Sell Power 12000 Zero-export Power 20
Energy pattern ☒ BattFirst ☐ LoadFirst
☒ Grid Peak Shaving 8000 Power ✓

Work Mode


Selling First: This Mode allows hybrid inverter to sell back any excess power produced by the solar panels to the grid. If time of use is active, the battery energy also can be sold into grid.

The PV energy will be used to power the load and charge the battery and then excess energy will flow to grid.


Power source priority for the load is as follows:

1. Solar Panels.
2. Grid.
3. Batteries (until programmable % discharge is reached).

Zero Export To Load: Hybrid inverter will only provide power to the backup load connected. The hybrid inverter will neither provide power to the home load nor sell power to grid. The built-in CT will detect power flowing back to the grid and will reduce the power of the inverter only to supply the local load and charge the battery.



Zero Export To CT: Hybrid inverter will not only provide power to the backup load connected but also give power to the home load connected. If PV power and battery power is insufficient, it will take grid energy as supplement. The hybrid inverter will not sell power to grid. In this mode, a CT is needed. The installation method of the CT please refer to chapter 3.6 CT Connection. The external CT will detect power flowing back to the grid and will reduce the power of the inverter only to supply the local load, charge battery and home load.



Solar Sell: "Solar sell" is for Zero export to load or Zero export to CT: when this item is active, the surplus energy can be sold back to grid. When it is active, PV Power source priority usage is as follows: load consumption and charge battery and feed into grid.

Max. sell power: Allowed the maximum output power to flow to grid

Zero-export Power: for zero-export mode, it tells the grid output power. Recommend to set it as 20-100W to ensure the hybrid inverter won't feed power to grid.

Energy Pattern: PV Power source priority.

Batt First: PV power is firstly used to charge the battery and then used to power the load. If PV power is insufficient, grid will make supplement for battery and load simultaneously.

Load First: PV power is firstly used to power the load and then used to charge the battery. If PV power is insufficient, Grid will provide power to load.

Max Solar Power: allowed the maximum DC input power

Grid Peak-shaving: when it is active, grid output power will be limited within the set value. If the load power exceeds the allowed value, it will take PV energy and battery as supplement. If still can't meet the load requirement, grid power will increase to meet the load needs.

System Work Mode

Grid Charge	Gen	Time Of Use Time	Power	Batt
<input type="checkbox"/>	<input type="checkbox"/>	01:00	5:00	+2000 45.0V
<input type="checkbox"/>	<input type="checkbox"/>	05:00	9:00	+2000 50.2V
<input checked="" type="checkbox"/>	<input type="checkbox"/>	09:00	13:00	+2000 50.9V
<input checked="" type="checkbox"/>	<input type="checkbox"/>	13:00	17:00	+2000 51.4V
<input checked="" type="checkbox"/>	<input type="checkbox"/>	17:00	21:00	+2000 47.1V
<input checked="" type="checkbox"/>	<input type="checkbox"/>	21:00	01:00	+2000 45.0V

Time Of Use ☒

Work Mode:

Time of use: it is used to program when to use grid or generator to charge the battery, and when to discharge the battery to power the load. Only tick "Time Of Use" then the follow items (Grid, charge, time, power etc.) will take effect.

Note: when in selling first mode and click time of use, the battery power can be sold into grid.

Grid charge: utilize grid to charge the battery in a time period.

Gen charge: utilize diesel generator to charge the battery in a time period.

Time: real time, range of 01:00-24:00.

Note: when the grid is present, only the "time of use" is ticked, then the battery will discharge. Otherwise, the battery won't discharge even the battery SOC is full. But in the off-grid mode (when grid is not available, inverter will work in the off-grid mode automatically).

Power: Max. discharge power of battery allowed.

Batt(V or SOC %): battery SOC % or voltage at when the action is to happen.

For example

During 01:00-05:00,

if battery SOC is lower than 80%, it will use grid to charge the battery until battery SOC reaches 80%.

During 05:00-08:00,

if battery SOC is higher than 40%, hybrid inverter will discharge the battery until the SOC reaches 40%. At the same time, if battery SOC is lower than 40%, then grid will charge the battery SOC to 40%.

During 08:00-10:00,

if battery SOC is higher than 40%, hybrid inverter will discharge the battery until the SOC reaches 40%.

During 10:00-15:00,

when battery SOC is higher than 80%, hybrid inverter will discharge the battery until the SOC reaches 80%.

During 15:00-18:00,

when battery SOC is higher than 40%, hybrid inverter will discharge the battery until the SOC reaches 40%.

During 18:00-01:00,

when battery SOC is higher than 35%, hybrid inverter will discharge the battery until the SOC reaches 35%.

Battery Setting

Start: 30% 30%

A: 40A 40A

Gen Charge ☐ Grid Charge ☒

Gen Signal ☐ Grid Signal ☒

Gen Max Run Time: 0.0 hours

Gen Down Time: 0.5 hours

Batt Set:

System Work Mode

Grid Charge ☒ Gen ☐ Time Of Use ☒

Time	Power	Batt
01:00	5:00	+2000 80%
05:00	9:00	+2000 40%
08:00	10:00	+2000 40%
10:00	15:00	+2000 80%
15:00	18:00	+2000 40%
18:00	01:00	+2000 35%

Work Mode:

System Work Mode

Mon ☒ Tue ☒ Wed ☒ Thu ☒ Fri ☒ Sat ☒ Sun ☐

Work Mode:

It allows users to choose which day to execute the setting of "Time of Use".

For example, the inverter will execute the time of use page on Mon/Tue/Wed/Thu/Fri/Sat only.

5.8 Grid Setup Menu

Grid Setting/Grid code selection

Grid Mode: **General Standard** 0/11

Grid Frequency: ☐ 50Hz ☒ 60Hz

Phase Type: ☐ 0/120/240 ☒ 0/240/120

Grid Level: **LN:230VAC LL:230VAC**

☐ IT system-neutral is not grounded

Grid Set1

Grid Set2

Grid Set3

Grid Mode: General Standard UL1741 & IEEE1547

CPUC RULE21SRD-UL-1741CEI 0-21Australia A

Australia BAustralia CEN50549_CZ-PPD5(>16A)

New Zealand VDE4105OVE-Directive R25.

Please follow the local grid code and then choose the corresponding grid standard.


Grid level: there're several voltage levels for the inverter output voltage when it is in off-grid mode.

LN:230VAC LL:400VAC, LN:240VAC LL:420VAC,

LN:120VAC LL:208VAC, LN:133VAC LL:230VAC.

IT system: if the grid system is IT system, then please

enable this option. For example, the IT grid system voltage is 230Vac (the Line voltage between any two live lines in a three-phase circuit is 230Vac, and the diagram is as follow) then please enable "IT system" and tick the "Grid level" as LN:133VAC LL:230VAC as below picture shows.



R_N: Large resistance ground resistor. Or the system doesn't have Neutral line.

Grid Setting/Grid code selection

Grid Mode: **General Standard** 0/11

Grid Frequency: ☐ 50Hz ☒ 60Hz

Phase Type: ☐ 0/120/240 ☒ 0/240/120

Grid Level: **LN:133VAC LL:230VAC**

☒ IT system-neutral is not grounded

Grid Set1

Grid Set2

Grid Set3

Grid Setting/Connect

Normal connect: **Normal Ramp rate: 10s**

Low frequency: **48.00Hz** High frequency: **51.30Hz**

Low voltage: **185.0V** High voltage: **265.0V**

Reconnect after trip: **Reconnect Ramp rate: 30s**

Low frequency: **48.00Hz** High frequency: **51.30Hz**

Low voltage: **185.0V** High voltage: **265.0V**

Reconnection Time: **60s** PF: **1.000**

Grid Set1

Grid Set2

Grid Set3

Normal connect: The allowed grid voltage/frequency range when the inverter first time connect to the grid.

Normal Ramp rate: It is the startup power ramp.

Reconnect after trip: The allowed grid voltage /frequency range for the inverter connects the grid after the inverter trip from the grid.

Reconnect Ramp rate: It is the reconnection power ramp.

Reconnection time: The waiting time period for the inverter connects the grid again.

PF: Power factor which is used to adjust inverter reactive power.

Grid Setting/IP Protection

Over voltage (V) (10 min. running mean): **265.0V**

HV1: **265.0V** - **0.10s** HV2: **51.30Hz** - **0.10s** HV3: **265.0V** - **0.10s**

LV1: **185.0V** - **0.10s** LV2: **48.00Hz** - **0.10s** LV3: **185.0V** - **0.10s**

HF1: **185.0V** - **0.10s** HF2: **48.00Hz** - **0.10s** HF3: **185.0V** - **0.10s**

LF1: **185.0V** - **0.10s** LF2: **48.00Hz** - **0.10s** LF3: **185.0V** - **0.10s**

Grid Set1

Grid Set2

Grid Set3

HV1: Level 1 overvoltage protection point;

HV2: Level 2 overvoltage protection point; ② 0.10s—Trip time.

HV3: Level 3 overvoltage protection point.

LV1: Level 1 undervoltage protection point;

LV2: Level 2 undervoltage protection point;

LV3: Level 3 undervoltage protection point.

HF1: Level 1 over frequency protection point;

HF2: Level 2 over frequency protection point;

HF3: Level 3 over frequency protection point.

LF1: Level 1 under frequency protection point;

LF2: Level 2 under frequency protection point;

LF3: Level 3 under frequency protection point.

Grid Setting/F(W)

☐ F(W)

Over frequency		Droop F		40%PE/Hz
Start freq F	50.20Hz	Stop freq F	51.5Hz	
Start delay F	0.00s	Stop delay F	0.00s	
Under frequency		Droop F		40%PE/Hz
Start freq F	49.80Hz	Stop freq F	49.50Hz	
Start delay F	0.00s	Stop delay F	0.00s	

Grid Set4

FW: this series inverter is able to adjust inverter output power according to grid frequency.

Droop F: percentage of nominal power per Hz

For example, "Start freq F50.2Hz, Stop freq F51.5, Droop F=40%PE/Hz" when the grid frequency reaches 50.2Hz, the inverter will decrease its active power at Droop F of 40%. And then when grid system frequency is less than 50.1Hz, the inverter will stop decreasing output power.

For the detailed setup values, please follow the local grid code.

Grid Setting/V(W) V(Q)

☐ V(W) ☐ V(Q)

V(W)		V(Q)	
Lock-in/Pn	Lock-out/Pn	Lock-in/Pn	Lock-out/Pn
5%	20%	5%	20%
V1	100.0%	P1	100%
V2	110.0%	P2	80%
V3	112.0%	P3	60%
V4	114.0%	P4	40%
V5	116.0%	P5	20%
V6	118.0%	P6	0%
V7	120.0%	P7	0%
V8	122.0%	P8	0%
V9	124.0%	P9	0%
V10	126.0%	P10	0%
V11	128.0%	P11	0%
V12	130.0%	P12	0%
V13	132.0%	P13	0%
V14	134.0%	P14	0%
V15	136.0%	P15	0%
V16	138.0%	P16	0%
V17	140.0%	P17	0%
V18	142.0%	P18	0%
V19	144.0%	P19	0%
V20	146.0%	P20	0%
V21	148.0%	P21	0%
V22	150.0%	P22	0%
V23	152.0%	P23	0%
V24	154.0%	P24	0%
V25	156.0%	P25	0%
V26	158.0%	P26	0%
V27	160.0%	P27	0%
V28	162.0%	P28	0%
V29	164.0%	P29	0%
V30	166.0%	P30	0%
V31	168.0%	P31	0%
V32	170.0%	P32	0%
V33	172.0%	P33	0%
V34	174.0%	P34	0%
V35	176.0%	P35	0%
V36	178.0%	P36	0%
V37	180.0%	P37	0%
V38	182.0%	P38	0%
V39	184.0%	P39	0%
V40	186.0%	P40	0%
V41	188.0%	P41	0%
V42	190.0%	P42	0%
V43	192.0%	P43	0%
V44	194.0%	P44	0%
V45	196.0%	P45	0%
V46	198.0%	P46	0%
V47	200.0%	P47	0%
V48	202.0%	P48	0%
V49	204.0%	P49	0%
V50	206.0%	P50	0%
V51	208.0%	P51	0%
V52	210.0%	P52	0%
V53	212.0%	P53	0%
V54	214.0%	P54	0%
V55	216.0%	P55	0%
V56	218.0%	P56	0%
V57	220.0%	P57	0%
V58	222.0%	P58	0%
V59	224.0%	P59	0%
V60	226.0%	P60	0%
V61	228.0%	P61	0%
V62	230.0%	P62	0%
V63	232.0%	P63	0%
V64	234.0%	P64	0%
V65	236.0%	P65	0%
V66	238.0%	P66	0%
V67	240.0%	P67	0%
V68	242.0%	P68	0%
V69	244.0%	P69	0%
V70	246.0%	P70	0%
V71	248.0%	P71	0%
V72	250.0%	P72	0%
V73	252.0%	P73	0%
V74	254.0%	P74	0%
V75	256.0%	P75	0%
V76	258.0%	P76	0%
V77	260.0%	P77	0%
V78	262.0%	P78	0%
V79	264.0%	P79	0%
V80	266.0%	P80	0%
V81	268.0%	P81	0%
V82	270.0%	P82	0%
V83	272.0%	P83	0%
V84	274.0%	P84	0%
V85	276.0%	P85	0%
V86	278.0%	P86	0%
V87	280.0%	P87	0%
V88	282.0%	P88	0%
V89	284.0%	P89	0%
V90	286.0%	P90	0%
V91	288.0%	P91	0%
V92	290.0%	P92	0%
V93	292.0%	P93	0%
V94	294.0%	P94	0%
V95	296.0%	P95	0%
V96	298.0%	P96	0%
V97	300.0%	P97	0%
V98	302.0%	P98	0%
V99	304.0%	P99	0%
V100	306.0%	P100	0%
V101	308.0%	P101	0%
V102	310.0%	P102	0%
V103	312.0%	P103	0%
V104	314.0%	P104	0%
V105	316.0%	P105	0%
V106	318.0%	P106	0%
V107	320.0%	P107	0%
V108	322.0%	P108	0%
V109	324.0%	P109	0%
V110	326.0%	P110	0%
V111	328.0%	P111	0%
V112	330.0%	P112	0%
V113	332.0%	P113	0%
V114	334.0%	P114	0%
V115	336.0%	P115	0%
V116	338.0%	P116	0%
V117	340.0%	P117	0%
V118	342.0%	P118	0%
V119	344.0%	P119	0%
V120	346.0%	P120	0%
V121	348.0%	P121	0%
V122	350.0%	P122	0%
V123	352.0%	P123	0%
V124	354.0%	P124	0%
V125	356.0%	P125	0%
V126	358.0%	P126	0%
V127	360.0%	P127	0%
V128	362.0%	P128	0%
V129	364.0%	P129	0%
V130	366.0%	P130	0%
V131	368.0%	P131	0%
V132	370.0%	P132	0%
V133	372.0%	P133	0%
V134	374.0%	P134	0%
V135	376.0%	P135	0%
V136	378.0%	P136	0%
V137	380.0%	P137	0%
V138	382.0%	P138	0%
V139	384.0%	P139	0%
V140	386.0%	P140	0%
V141	388.0%	P141	0%
V142	390.0%	P142	0%
V143	392.0%	P143	0%
V144	394.0%	P144	0%
V145	396.0%	P145	0%
V146	398.0%	P146	0%
V147	400.0%	P147	0%
V148	402.0%	P148	0%
V149	404.0%	P149	0%
V150	406.0%	P150	0%
V151	408.0%	P151	0%
V152	410.0%	P152	0%
V153	412.0%	P153	0%
V154	414.0%	P154	0%
V155	416.0%	P155	0%
V156	418.0%	P156	0%
V157	420.0%	P157	0%
V158	422.0%	P158	0%
V159	424.0%	P159	0%
V160	426.0%	P160	0%
V161	428.0%	P161	0%
V162	430.0%	P162	0%
V163	432.0%	P163	0%
V164	434.0%	P164	0%
V165	436.0%	P165	0%
V166	438.0%	P166	0%
V167	440.0%	P167	0%
V168	442.0%	P168	0%
V169	444.0%	P169	0%
V170	446.0%	P170	0%
V171	448.0%	P171	0%
V172	450.0%	P172	0%
V173	452.0%	P173	0%
V174	454.0%	P174	0%
V175	456.0%	P175	0%
V176	458.0%	P176	0%
V177	460.0%	P177	0%
V178	462.0%	P178	0%
V179	464.0%	P179	0%
V180	466.0%	P180	0%
V181	468.0%	P181	0%
V182	470.0%	P182	0%
V183	472.0%	P183	0%
V184	474.0%	P184	0%
V185	476.0%	P185	0%
V186	478.0%	P186	0%
V187	480.0%	P187	0%
V188	482.0%	P188	0%
V189	484.0%	P189	0%
V190	486.0%	P190	0%
V191	488.0%	P191	0%
V192	490.0%	P192	0%
V193	492.0%	P193	0%
V194	494.0%	P194	0%
V195	496.0%	P195	0%
V196	498.0%	P196	0%
V197	500.0%	P197	0%
V198	502.0%	P198	0%
V199	504.0%	P199	0%
V200	506.0%	P200	0%
V201	508.0%	P201	0%
V202	510.0%	P202	0%
V203	512.0%	P203	0%
V204	514.0%	P204	0%
V205	516.0%	P205	0%
V206	518.0%	P206	0%
V207	520.0%	P207	0%
V208	522.0%	P208	0%
V209	524.0%	P209	0%
V210	526.0%	P210	0%
V211	528.0%	P211	0%
V212	530.0%	P212	0%
V213	532.0%	P213	0%
V214	534.0%	P214	0%
V215	536.0%	P215	0%
V216	538.0%	P216	0%
V217	540.0%	P217	0%
V218	542.0%	P218	0%
V219	544.0%	P219	0%
V220	546.0%	P220	0%
V221	548.0%	P221	0%
V222	550.0%	P222	0%
V223	552.0%	P223	0%
V224	554.0%	P224	0%
V225	556.0%	P225	0%
V226	558.0%	P226	0%
V227	560.0%	P227	0%
V228	562.0%	P228	0%
V229	564.0%	P229	0%
V230	566.0%	P230	0%
V231	568.0%	P231	0%
V232	570.0%	P232	0%
V233	572.0%	P233	0%
V234	574.0%	P234	0%
V235	576.0%	P235	0%
V236	578.0%	P236	0%
V237	580.0%	P237	0%
V238	582.0%	P238	0%
V239	584.0%	P239	0%
V240	586.0%	P240	0%
V241	588.0%	P241	0%
V242	590.0%	P242	0%
V243	592.0%	P243	0%
V244	594.0%	P244	0%
V245	596.0%	P245	0%
V246	598.0%	P246	0%
V247	600.0%	P247	0%
V248	602.0%	P248	0%
V249	604.0%	P249	0%
V250	606.0%	P250	0%
V251	608.0%	P251	0%
V252	610.0%	P252	0%
V253	612.0%	P253	0%
V254	614.0%	P254	0%
V255	616.0%	P255	0%
V256	618.0%	P256	0%
V257	620.0%	P257	0%
V258	622.0%	P258	0%
V259	624.0%	P259	0%
V260	626.0%	P260	0%
V261	628.0%	P261	0%
V262	630.0%	P262	0%
V263	632.0%	P263	0%
V264	634.0%	P264	0%
V265	636.0%	P265	0%
V266	638.0%	P266	0%
V267	640.0%	P267	0%
V268	642.0%	P268	0%
V269	644.0%	P269	0%
V270	646.0%	P270	0%
V271	648.0%	P271	0%
V272	650.0%	P272	0%
V2			

5.9 Generator Port Use Setup Menu

GEN PORT USE

Mode

☐ Generator Input ☐ GEN connect to Grid Input

Rated Power: 8000W

☐ SmartLoad Output ☐ On Grid always on

AC Couple Fz High: 55.00Hz

☐ Micro Inv Input ☐ Off/ON: 51.0V / 54.0V

☐ All export to Grid output

PORT Set

Generator input rated power: allowed Max. power from diesel generator.

GEN connect to grid input: connect the diesel generator to the grid input port.

Smart Load Output: This mode utilizes the Gen input connection as an output which only receives power when the battery SOC is above a user programmable threshold.

e.g. ON: 100%, OFF=95%: When the battery bank SOC reaches 100%, Smart Load Port will switch on automatically and power the load connected. When the battery bank SOC < 95%, the Smart Load Port will switch off automatically.

Smart Load OFF Batt

- Battery SOC at which the Smart load will switch off.

Smart Load ON Batt

- Battery SOC at which the Smart load will switch on, simultaneously and then the Smart load will switch on.

On Grid always on: When click "on Grid always on" the smart load will switch on when the grid is present.

Micro Inv Input: To use the Generator input port as a micro-inverter on grid inverter input (AC coupled), this feature will also work with "Grid-Tied" inverters.

Micro Inv Input OFF: when the battery SOC exceeds setting value, Microinverter or grid-tied inverter will shut down.

Micro Inv Input ON: when the battery SOC is lower than setting value, Microinverter or grid-tied inverter will start to work.

AC Couple Fz High: If choosing "Micro Inv input", as the battery SOC reaches gradually setting value (OFF). During the process, the microinverter output power will decrease linear. When the battery SOC equals to the setting value (OFF), the system frequency will become the setting value (AC couple Fz high) and the Microinverter will stop working.

All export to grid cutoff: Stop exporting power produced by the microinverter to the grid.

Note: Micro Inv Input OFF and On is valid for some certain FW version only.

5.10 Advanced Function Setup Menu

Advanced Function

☐ Solar Arc-Fault ON

☐ Clear Arc-Fault

☐ System selfcheck

☐ CT Ratio

☐ Signal Island Mode

☐ Asymmetric phase feeding

Backup Delay: 0ms

Gen peak-shaving: 2000

BMS_Err_Stop: 3000

CSI Report

Func Set

Solar Arc Fault ON: This is only for US.

System selfcheck: Disable, this is only for factory.

Gen Peak-shaving: Enable When the power of the generator exceeds the rated value of it, the inverter will provide the redundant part to ensure that the generator will not overload.

DRM: For AS4777 standard.


Backup Delay: When the grid cuts off, the inverter will give output power after the setting time.

For example, backup delay: 3ms, the inverter will give output power after 3ms when the grid cuts off.

Note: for some old FW version, the function is not available

BMS_Err_Stop: When it is active, if the battery BMS failed to communicate with inverter, the inverter will stop working and report fault.

Signal island mode: If "Signal island mode" is checked and When inverter is in off-grid mode, the relay on the Neutral line (load port N line) will switch ON then the N line (load port N line) will bind to inverter ground.




Asymmetric phase feeding: If it was checked, the inverter will take power from the grid balance of on each phase (L1/L2/L3) when needed.

Advanced Function

☐ DC 1 for WindTurbine
 ☐ DC 2 for WindTurbine

V1	20V	0.0A	V7	210V	0.0A
V2	110V	1.0A	V8	220V	10.0A
V3	130V	3.0A	V9	250V	12.0A
V4	150V	4.0A	V10	270V	13.0A
V5	170V	5.0A	V11	290V	15.0A
V6	190V	7.0A	V12	310V	18.0A

Wind Set2
 ↑
 ↓
 ✕
 ✓



Advanced Function

☐ Parallel
☐ Master
☒ Slave

Module SN
 00

☐ EX_Meter For CT
 Meter Select
 00
 CHNT
 Easton

Parallel Set3
 ↑
 ↓
 ✕
 ✓

Ex_Meter For CT: when using zero-export to CT mode, the hybrid inverter can select EX_Meter For CT function and use the different meters.e.g.CHNT and Easton.

5.11 Device Info Setup Menu

Device Info.

Version Info
 Fault Log

Device Info.

18K
 Inverter SN: 2404098579 Flash
 HMI: Ver 1001-C047
 MAIN: Ver 2021-1145-1807
 ARC: Ver 020E

Device Info.

Alarms Code	Occurred
F56 DC_VoltLow_Fault	2024-04-29 09:33
F13 Grid_Mode_changed	2024-04-29 07:22
F13 Grid_Mode_changed	2024-04-29 03:22
F56 DC_VoltLow_Fault	2024-04-29 03:11

Device Info
 ↑
 ↓
 ✕
 ✓


These page show Inverter ID, Inverter version and alarm codes.

HMI: LCD version


MAIN: Control board FW version.

6. Mode


Mode I: Basic




Mode II: With Generator



Mode III: With Smart-Load



Mode IV: AC Couple





The 1st priority power of the system is always the PV power, then 2nd and 3rd priority power will be the battery bank or grid according to the settings. The last power backup will be the Generator if it is available.

7. Limitation of Liability

In addition to the product warranty described above, the state and local laws and regulations provide financial compensation for the product's power connection (including violation of implied terms and warranties). The company hereby declares that the terms and conditions of the product and the policy can and can only legally exclude all liability within a limited scope.

[illegible]

[illegible]

<i>Error code</i>	<i>Description</i>	<i>Solutions</i>

Chart 7-1 Fault information

Under the guidance of our company, customers return our products so that our company can provide service of maintenance or replacement of products of the same value. Customers need to pay the necessary freight and other related costs. Any replacement or repair of the product will cover the remaining warranty period of the product. If any part of the product or product is replaced by the company itself during the warranty period, all rights and interests of the replacement product or component belong to the company.

Factory warranty does not include damage due to the following reasons:

- Damage during transportation of equipment
- Damage caused by incorrect installation or commissioning
- Damage caused by failure to comply with operation instructions, installation instructions or maintenance instructions
- Damage caused by attempts to modify, alter or repair products
- Damage caused by incorrect use or operation
- Damage caused by insufficient ventilation of equipment
- Damage caused by failure to comply with applicable safety standards or regulations
- Damage caused by natural disasters or force majeure (e.g. floods, lightning, overvoltage, storms, fires, etc.)

In addition, normal wear or any other failure will not affect the basic operation of the product. Any external scratches, stains or natural mechanical wear does not represent a defect in the product.

8. Datasheet



Model	SUN-14K-SG0SLP3-EU-SM2	SUN-15K-SG0SLP3-EU-SM2	SUN-16K-SG0SLP3-EU-SM2	SUN-18K-SG0SLP3-EU-SM2	SUN-20K-SG0SLP3-EU-SM2
Battery Input Data					
Battery Type	Lead-acid or Lithium-ion				
Battery Voltage Range(V)	40-60				
Max. Charging Current(A)	260	280	300	330	350
Max. Discharging Current(A)	260	280	300	330	350
Charging Strategy for Li-ion Battery	Self-adaption to BMS				
Number of Battery Input	2				
PV String Input Data					
Max. PV Input Power(W)	21000	22500	24000	27000	30000
Max. PV Input Voltage(V)	800				
Start-up Voltage(V)	160				
PV Input Voltage Range(V)	160-800				
MPPT Voltage Range(V)	160-650				
Full Load MPPT Voltage Range(V)	330-650	350-650	380-650	420-650	470-650
Rated PV Input Voltage(V)	550				
Max. Operating PV Input Current(A)	36+20				
Max. Input Short-Circuit Current(A)	54+30				
No. of MPP Trackers/No. of Strings MPP Tracker	2/2+1				
Max. Inverter Backfeed Current to The Array	0				
AC Input/Output Data					
Rated AC Input/Output Active Power(W)	14000	15000	16000	18000	20000
Max. AC Input/Output Apparent Power(VA)	15400	16500	17600	19800	22000
Peak Power (off-grid)(W)	2 times of rated power, 10s				
Rated AC Input/Output Current(A)	21.3/20.3	22.8/21.8	24.3/23.2	27.3/26.1	30.4/29
Max. AC Input/Output Current(A)	21.3/20.3	22.8/21.8	24.3/23.2	27.3/26.1	30.4/29
Max. Continuous AC Passthrough (grid to load)(A)	70				
Max. Output Fault Current(A)	46.8	50	53.4	60	66.8
Max. Output Overcurrent Protection(A)	94				
Rated Input/Output Voltage/Range(V)	220/380V,230/400V 0.85Un-1.1Un				
Grid Connection Form	3L+N+PE				
Rated Input/Output Grid Frequency/Range	50Hz/45Hz-55Hz 60Hz/55Hz-65Hz				
Power Factor Adjustment Range	0.8 leading-0.8 lagging				
Total Current Harmonic Distortion THDi	<3% (of nominal power)				
DC Injection Current	<0.5%In				
Efficiency					
Max. Efficiency	97.60%				
Euro Efficiency	97.00%				
MPPT Efficiency	>99%				
Equipment Protection					
DC Polarity Reverse Connection Protection	Yes				
AC Output Overcurrent Protection	Yes				
AC Output Overvoltage Protection	Yes				
AC Output Short Circuit Protection	Yes				
Thermal Protection	Yes				
DC Terminal Insulation Impedance Monitoring	Yes				

DC Component Monitoring	Yes
Ground Fault Current Monitoring	Yes
Power Network Monitoring	Yes
Island Protection Monitoring	Yes
Earth Fault Detection	Yes
DC Input Switch	Yes
Overvoltage Load Drop Protection	Yes
Residual Current (RCD) Detection	Yes
Surge Protection Level	TYPE II(DC), TYPE II(AC)
Interface	
Display	LCD+LED
Communication Interface	RS232, RS485, CAN
Monitor Mode	GPRS/WIFI/Bluetooth/4G/LAN(optional)
General Data	
Operating Temperature Range	-40 to +60, >45 Derating
Permissible Ambient Humidity	0-100%
Permissible Altitude	3000m
Noise	60 dB
Ingress Protection(IP) Rating	IP 65
Inverter Topology	Non-Isolated
Over Voltage Category	OVC II(DC), OVC III(AC)
Cabinet size(W*H*D) [mm]	456W×750H×268.5D (Excluding connectors and brackets)
Weight(kg)	50.6
Warranty	5 Years/10 Years the Warranty Period Depends the Final Installation Site of Inverter, More Info Please Refer to Warranty Policy
Type of Cooling	Intelligent Air Cooling
Grid Regulation	IEC 61727, IEC 62116, CEI 0-21, EN 50549, NRS 097, RD 140, UNE 217002, OVE-Richtlinie R25, G99, VDE-AR-N 4105
Safety EMC/Standard	IEC/EN 61000-6-1/2/3/4, IEC/EN 62109-1, IEC/EN 62109-2

9. Appendix I



Definition of RJ45 Port Pin for BMS

BMS 485/CAN Port



Definition of RJ45 Port Pin for Meter-485



Meter-485 Port



Definition of RJ45 Port Pin of "Modbus port" for remotely monitoring



	Modbus port

Modbus port



DRMit is used to accept the external control command.

Definition of RJ45 Port Pin for DRM



(PIN 6 REF_2)


PIN 5 REF_1

PIN 4 DI 4

PIN 3 DI 3


PIN 2 DI 2

PIN 1 DI 1




Inverter

RCR




RS232



This RS232 port is used to connect the wifi datalogger

10. Appendix II

1. Split Core Current Transformer (CT) dimension: (mm)
2. Secondary output cable length is 4m.



11. EU Declaration of Conformity

within the scope of the EU directives

- Electromagnetic compatibility 2014/30/EU (EMC)
- Low Voltage Directive 2014/35/EU (LVD)
- Restriction of the use of certain hazardous substances 2011/65/EU (RoHS)



NINGBO DEYE INVERTER TECHNOLOGY CO., LTD. confirms herewith that the products described in this document are in compliance with the fundamental requirements and other relevant provisions of the above mentioned directives. The entire EU Declaration of Conformity and certificate can be found at <https://www.deyeinverter.com/download/#hybrid-inverter-5>.

EU Declaration of Conformity

Product: Hybrid Inverter

Models: SUN-14K-SG05LP3-EU-SM2; SUN-15K-SG05LP3-EU-SM2; SUN-16K-SG05LP3-EU-SM2;
SUN-18K-SG05LP3-EU-SM2; SUN-20K-SG05LP3-EU-SM2

Name and address of the manufacturer: Ningbo Deye Inverter Technology Co., Ltd.
No. 26 South Yongqiang Road, Dagli, Beilun, Ningbo, China

This declaration of conformity is issued under the sole responsibility of the manufacturer. Also this product is under manufacturer's warranty.

This declaration of conformity is not valid any longer, if the product is modified, supplemented or changed in any other way, as well as in case the product is used or installed improperly.

The object of the declaration described above is in conformity with the relevant Union harmonization legislation: The Low Voltage Directive (LVD) 2014/35/EU; the Electromagnetic Compatibility (EMC) Directive 2014/30/EU; the restriction of the use of certain hazardous substances (RoHS) Directive 2011/65/EU.

References to the relevant harmonized standards used or references to the other technical specifications in relation to which conformity is declared:

LVD:	
EN 62109-1:2010	●
EN 62109-2:2011	●
EMC:	
EN IEC 61000-6-1:2019	●
EN IEC 61000-6-2:2019	●
EN IEC 61000-6-3:2021	●
EN IEC 61000-6-4:2019	●
EN IEC 61000-3-2:2019/A1:2021	●
EN 61000-3-3:2013/A2:2021/AC:2022-01	●
EN IEC 61000-3-11:2019	●
EN 61000-3-12:2011	●
EN 55011:2016/A2:2021	●
EN 62220:2017+A11+A1	●

Nom et Titre / Name and Title:

Bard Dai
Senior Standard and Certification Engineer

Au nom de / On behalf of:
Date / Date (yyyy-mm-dd):
A / Place:
EU Declaration of

Ningbo Deye Inverter Technology Co., Ltd.
2024-05-08
Ningbo, China

Ningbo Deye Inverter Technology Co., Ltd.
No. 26 South Yongqiang Road, Dagli, Beilun, Ningbo, China

NINGBO DEYE INVERTER TECHNOLOGY CO., LTD.



30240301003144